EXPLANATION - HOW THIS SYSTEM OPERATES

To operate, hook the pressure system to the cabinet by connecting a 4 inch flex hose from the bottom of the cabinet to the RECLAIM INLET. The suction from the dust collector pulls the media out of the bottom of the cabinet into the RECLAIM BODY. The media spins around an inner cylinder, which is connected to the DUST COLLECTOR RETURN HOSE, inside the RECLAIM BODY. The heavy reusable media will fall into the RECLAIM HOPPER and then reloads into the blast pot when the foot pedal is released. The lighter particles that are smaller, such as dust, gets sucked up into the DUST COLLECTOR RETURN HOSE and into the DUST COLLECTOR. When stepping on the pedal to blast, the pressure pot pressurizes and the media is forced out the METERING VALVE and through a hose and nozzle that is connected to the METERING VALVE and into the cabinet.

