

SPRAY WASH CABINET

Operating Instructions

1. Power requirement: 220V, Single Phase, 30 amp
2. 3-Pin power outlet needed.
3. Remove 2 blue, round rubbers and adjust latch length.
4. Fill water into tank and check if the water level is 9 1/4.”
Then put approximately 8 lb of detergent into water.
5. Turn on the 30 amp circuit breaker to heat the water for at least 30 minutes.
6. Place big parts on the turntable and small parts in the basket.
7. Close and latch the door.
8. Turn on the 20 amp circuit breaker and timer to wash the parts.
9. After washing, turn on the skimmer-cycle timer to skim waste oil off the surface of the water.
10. After skimming, turn off both the 30 amp and the 20 amp circuit breakers and pull off the plug.