




The Stinger Folding Motorcycle Trailer

**Stinger For Trike
Owners Manual
&
Warranty Information**



www.stingertrailer.com

Stinger

For Trike



User Manual




Stinger Trailer

www.stingertrailer.com Call Toll Free 1 800 577 8809





For Trike




User Manual

1 Unfolding




Turn the Arm
to the Front




Use Tire Stopper to Unfold

2 Install Pins




Lift and
secure Chocks



Forward & Chock Pin



Mid Pin

Center Pins



Rear Gate Pin

3 Ready to Load



Stinger Trailer

www.stingertrailer.com Call Toll Free 1 800 577 8809

PLEASE READ BEFORE USING YOUR

STINGER TRAILER

1. Remove all four (4) pins before unfolding trailer.
2. Trailer must be hooked to vehicle before loading or unloading motorcycle.
3. Be certain that both ½" pins are installed in trailer before loading motorcycle. Also, be sure to insert the retaining pins located at each location. The 3/8" pin holds ramp upright after loading.
4. Read instruction label located on trailer tongue.
5. Bearings should be greased every 2,000 miles OR annually (see www.stingertrailer.com for greasing video)
6. Trailer comes with flat four electrical plug. Owner needs to wire towing vehicle. (Some vehicles may require an inverter).
7. Inflate tires evenly (35-70 lbs as preferred) at all times.
8. Trailer must be level once mounted. Adjustable ball mounts work well for this. If you are unable to perfectly level, it is best to have the coupler slightly elevated.
9. When folding and unfolding trailer, use the front tie-down bar as a handle. Make sure hands are not placed at the folding sections of the trailer when folding and unfolding to avoid pinching of hands.
10. Check bolts on trailer before each use. Especially fenders!
11. Be careful not to pinch electrical cable when folding trailer.
12. Be sure to use at least four (4) straps to tie down bike (see www.stingertrailer.com for tie down video)

Visit www.stingertrailer.com for video demonstrations

STINGER TRAILER LIMITED WARRANTY

Stingertrailer.com warrants to the original retail purchaser that the Stinger Trailer is free from defects in material and workmanship; and agrees to repair or replace, at Stingertrailer.com's discretion. Any defective parts are free of charge within Two (2) years from the date of purchase, if the product is used for personal use only.

The warranty is not transferable and does not cover damage that is a result of defects, other than in material or workmanship. Warranty does not cover damage caused by unreasonable use, including the failure to provide reasonable and necessary maintenance. Also, the warranty obligations do not apply to conditions resulting from misuse, alteration, or accident. In addition, this warranty does not cover replacement of non-defective parts (such as electrical wires and plugs, tires and lights) that may wear and need to be replaced within the warranty period in connection to regular maintenance.

DAMAGES NOT COVERED UNDER WARRANTY DUE TO MISUSE

Warranty will not cover damages caused by travelling more than the designated 80 mph maximum that the tires are rated at, as well as not following instruction labels located on trailer and instruction sheet provided to consumer at time of purchase.

HOW TO OBTAIN WARRANTY SERVICE

Warranty service can be obtained from Stingertrailer.com (1-800-577-8809). Shipping charges for parts sent back to the repair center are the responsibility of the purchaser depending on the type of defect to the product.

www.stingertrailer.com